



**SCHURTER**
ELECTRONIC COMPONENTS

Schurter

**SCHURTER**
ELECTRONIC COMPONENTS


CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S

Tau Wae:	CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NC 100MA 42V
Ngā Rauemi:	 CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S.pdf
RoHs Tūnga	 Whakahaerehia te kore utu / RoHS
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.













Ngā whakaaturanga o CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S

TAU WAE	CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NC 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
PEPA RARAUNGA	 CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	On-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 16.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Magenta/White
NGĀ ĀHUATANGA	G Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST-NC
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Kaitoha CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Kaiwhakaratō CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S
Utu CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Pikitia CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Whakaahua CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S
CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S Pepa Raraunga PDF	CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S Tango Whakahoki	Tapunga CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S
Hokona CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Hokona CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Hokona Schurter CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S
Schurter CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Kaiwhakaratō Schurter	Kaitoha Kaatawhai Schurter
Schurter CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	Schurter Inc. CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1007-S	

Ngā Hua e hāngai ana

<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1010-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1006-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1012-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1002-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1008-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1001-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1013-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1003-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1011-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1005-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1004-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS16-NC00A10-SNCSNCNF-RI0MWVAR-W1009-S</div> <div>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</div> <div>RFQ</div>