





Schurter




## CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S

Tau Wae:	CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NO 100MA 42V
Ngā Rauemi:	 CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S.pdf
RoHS Tūnga	 Whakahaerehia te kore utu / RoHS
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

[TONO MO TE WHAKAHUA](#)

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.





### Ngā whakaaturanga o CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S

TAU WAE	CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NO 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
PEPA RARAUNGA	 CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 22.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Blue/White
NGĀ ĀHUATANGA	Ceramic Actuator, Finger Guide, O Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST-NO
MOMO KAIHOKO	Round, Button, Flush

### Ngā tūtohu e hāngai ana

Schurter CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Kaitoha CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Kaiwhakarato CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S
Utu CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Pikitia CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Whakaahua CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S
CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S Pepa Raraunga PDF	CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S Tango Whakahoki	Tapunga CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S
Hokona CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Hokona CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Hokona Schurter CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S
Schurter CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Kaiwhakarato Schurter	Kaitoha Kaatawhai Schurter
Schurter CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	Schurter Inc. CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1015-S	

### Ngā Hua e hāngai ana

 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1010-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1018-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1021-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1016-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1017-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1014-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1020-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1011-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1009-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1013-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>
 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1012-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>	 <p><b>CPS22-NO00A10-SNCCWTWF-AIOBWWAR-W1019-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><a href="#">RFQ</a></p>