





Schurter




CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S

Tau Wae:	CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NC 100MA 42V
Ngā Rauemi:	 CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S.pdf
RoHS Tūnga	 Whakahaerehia te kore utu / RoHS
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.













Ngā whakaaturanga o CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S

TAU WAE	CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NC 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
PEPA RARAUNGA	 CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	On-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 19.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Magenta/Yellow
NGĀ ĀHUATANGA	Ceramic Actuator, Finger Guide, LOCK Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST-NC
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Kaitoha CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Kaiwhakarato CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S
Utu CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Pikitia CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Whakaahua CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S
CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S Pepa Raraunga PDF	CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S Tango Whakahoki	Tapunga CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S
Hokona CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Hokona CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Hokona Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S
Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Kaiwhakarato Schurter	Kaitoha Kaatawhai Schurter
Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	Schurter Inc. CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S	

Ngā Hua e hāngai ana

 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1050-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>	 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1053-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>
 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1052-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>	 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1060-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>
 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>	 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1057-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>
 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1058-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>	 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1061-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>
 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1055-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>	 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1062-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>
 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1059-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>	 <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1054-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <div style="text-align: center; background-color: #f0f0f0; padding: 5px; font-weight: bold;">RFQ</div>