





Schurter




## CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S

Tau Wae:	CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	 CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S.pdf
RoHS Tūnga	 Whakahaerehia te kore utu / RoHS
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

**TONO MO TE WHAKAHUA**

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

### Ngā whakaaturanga o CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S

TAU WAE	CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
PEPA RARAUNGA	 CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 16.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Cyan
NGĀ ĀHUATANGA	Finger Guide, L Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

### Ngā tūtohu e hāngai ana

Schurter CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Kaitoha CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Kaiwhakarato CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S
Utu CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Pikitia CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Whakaahua CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S
CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S Pepa Raraunga PDF	CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S Tango Whakahoki	Tapunga CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S
Hokona CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Hokona CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Hokona Schurter CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S
Schurter CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Kaiwhakarato Schurter	Kaitoha Kaatawhai Schurter
Schurter CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	Schurter Inc. CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1012-S	

### Ngā Hua e hāngai ana

 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1017-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1006-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1018-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1010-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1016-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1007-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1011-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1014-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1015-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1008-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1013-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-LA00A10-SNCSNCWF-RI0CYVAR-W1009-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>