

CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S

| | |
|---------------------|---|
| Tau Wae: | CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S |
| Kaihanga / Waitohu: | Schurter |
| Whakaahuatanga hua | SWITCH PUSH SPST-NC 100MA 42V |
| Ngā Rauemi: | CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S.pdf |
| RoHS Tūnga | Whakahaerehia te kore utu / RoHS |
| Tuhinga mai i | Hong Kong |
| Te Ara Tuhi | DHL/Fedex/TNT/UPS/EMS |

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S

| | |
|---|--|
| TAU WAE | CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S |
| KAIHANGA | Schurter |
| WHAKAAHUATANGA | SWITCH PUSH SPST-NC 100MA 42V |
| WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA | Whakahaerehia te kore utu / RoHS |
| PEPA RARAUNGA | CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S.pdf |
| WHAKAAETANGA NGAOHIKO - DC | 60V |
| WHAKAAETANGA NGAOHIKO - AC | 42V |
| MOMO | Capacitive, Illuminated |
| KĀHUA WHAKAMUTUNGA | Wire Leads |
| WHAKAWHITI MAHINGA | On-Mom |
| RAUPAPA | CPS |
| PIHANGA WHAKAPAE PAEPAE | Circular - 19.10mm Dia |
| PACKAGING | Bulk |
| TAE MAHI | -40°C ~ 60°C |
| MOMO TAE | Panel Mount, Front |
| TAUMATA WHAKAARO MOE (MSL) | 1 (Unlimited) |
| TE MAHI MOMO | - |
| WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA | Lead free / RoHS Compliant |
| TIAKI INGOA | IP67 - Dust Tight, Waterproof |
| WHAKAKAMAHI WHAKAKUKU (NOMINAL) | 5 ~ 28 VDC |
| MOMO WHAKAMARAMA, TAE | LED, Magenta/Yellow |
| NGĀ ĀHUATANGA | Ceramic Actuator, Finger Guide, Percentage Symbol |
| TE ORANGA RAWA | - |
| WHAKAAHUATANGA TAIPITOPITO | Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front |
| WHAKATAURANGA ONAMATA | 100mA (AC/DC) |
| TAE - KAIHOAHOA / KAPORO | Clear (White Filter/Diffuser) |
| TAKAHANGA | SPST-NC |
| MOMO KAIHOKO | Round, Button, Flush |

Ngā tūtohu e hāngai ana

| | | |
|---|---|---|
| Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Kaitoha CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Kaiwhakarato CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S |
| Utu CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Pikitia CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Whakaahua CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S |
| CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S Pepa Raraunga PDF | CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S Tango Whakahoki | Tapunga CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S |
| Hokona CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Hokona CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Hokona Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S |
| Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Kaiwhakarato Schurter | Kaitoha Kaatawhai Schurter |
| Schurter CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | Schurter Inc. CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1051-S | |

Ngā Hua e hāngai ana

| | |
|---|---|
| <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1052-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1056-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1055-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1049-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1054-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1046-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1050-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1057-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1047-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1045-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1048-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS19-NC00A10-SNCCWTWF-AI0MYVAR-W1053-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |