





**Schurter**



**CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S**

Tau Wae:	CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NO 100MA 42V
Ngā Rauemi:	 CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S.pdf
RoHS Tūnga	 Whakahaerehia te kore utu / RoHS
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

**TONO MO TE WHAKAHUA**

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.













**Ngā whakaaturanga o CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S**

TAU WAE	CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NO 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
PEPA RARAUNGA	 CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 16.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, White/Green
NGĀ ĀHUATANGA	Ceramic Actuator, Finger Guide, Root Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST-NO
MOMO KAIHOKO	Round, Button, Flush

**Ngā tūtohu e hāngai ana**

Schurter CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Kaitoha CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Kaiwhakarato CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S
Utu CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Pikitia CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Whakaahua CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S
CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S Pepa Raraunga PDF	CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S Tango Whakahoki	Tapunga CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S
Hokona CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Hokona CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Hokona Schurter CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S
Schurter CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Kaiwhakarato Schurter	Kaitoha Kaatawhai Schurter
Schurter CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	Schurter Inc. CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1052-S	

**Ngā Hua e hāngai ana**

 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1057-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1047-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1054-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1055-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1050-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1046-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1048-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1051-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1056-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1049-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1058-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS16-NO00A10-SNCCWTWF-AI0WGVAR-W1053-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: Out stock</p> <p><b>RFQ</b></p>