

**Schurter**

## CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S

Tau Wae:	CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NC 100MA 42V
Ngā Rauemi:	CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

### Ngā whakaaturanga o CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S

TAU WAE	CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NC 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
PEPA RARAUNGA	CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	On-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 22.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Green/Blue
NGĀ ĀHUATANGA	F Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST-NC
MOMO KAIHOKO	Round, Button, Flush

### Ngā tūtohu e hāngai ana

Schurter CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Kaitoha CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Kaiwhakarato CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S
Utu CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Pikitia CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Whakaahua CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S
CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S Pepa Raraunga PDF	CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S Tango Whakahoki	Tapunga CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S
Hokona CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Hokona CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Hokona Schurter CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S
Schurter CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Kaiwhakarato Schurter	Kaitoha Kaatawhai Schurter
Schurter CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	Schurter Inc. CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1006-S	

### Ngā Hua e hāngai ana

<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1002-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>	<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1010-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>
<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1009-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>	<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1007-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>
<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W0000-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>	<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1003-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>
<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1011-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>	<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1004-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>
<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1012-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>	<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1008-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>
<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1005-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>	<p><b>CPS22-NC00A10-SNCSNCF-RI0GBVAR-W1001-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: Out stock</p> <p style="text-align: center; background-color: #ccc; padding: 2px;"><b>RFQ</b></p>